

What's Included

- 1. The Sound Bay X wireless stereo headphones
- 2. Micro USB charging cable
- 3. 3.5mm Audio cable
- 4. User guide and warranty card

Specifications

Model: Model X Weight: 0.6 lbs

BT Version: BT5.0 + EDR, HSP/HFP/A2DP/AVRCP

Battery: Li-ion Battery, 430mAh

Functions: Wireless, Noise Canceling, Mic Water Resistant Standard: IPX-5

Standby Time: 160 Hours Charging Time: About 2 Hours Music Time: 17-18 Hours Operation range: Up to 50 ft Frequency: 2.402GHz-2.48GHz Speaker Impedance: 32 ohm

Sensitivity: 96 dB/mW

Quick Start

1. Wireless Pairing

With the headphones off, press and hold the power button for about 4-5 seconds until the red and blue indicators start to flash. Then turn on the bluetooth function on your phone.


Search for bluetooth devices and select
"SoundBay X".

2. Charging the Battery

Use the complimentary charging cable or any micro USB charging cable to charge the device. The indicator light will be red while charging. Once the device is fully charged, the indicator light will be turned off.

3. Wired Mode

Plug in the 3.5mm audio cable to turn on Wired mode. Note that the buttons and microphone will be not available, and you will not be able to make or receive any calls.



Button Name	Action	Result
(a)	Press and hold for 3-5 seconds	ON/Pairing
9	Press and hold for 3-5 seconds	OFF
(b)	Press the button	Play/Pause
(a)	Press the button	Answer/Hang up
G	Press and hold for 3 seconds	Reject
+	Press when music is playing	Volume up
•	Press when music is playing	Volume down
•	Press and hold when music is playing	Next Track
•	Press and hold when music is playing	Previous Track
©	Double click	LED color switch

Troubleshooting

1. The device is not found

If the phone cannot find the device, try to turn off the headphones and then turn them on. Try to turn off the bluetooth on your phone and turn it on too. Then remove the bluetooth device on the phone, search and pair again.

2. The device is connected, but there is no sound

Adjust the volume on the headset; it might be set to the lowest level.

3. There is no sound when you plug in the audio cable

Make sure the audio cable is plugged in your headphones and phone.

Questions?

Please email our customer service: support@thesoundbay.com

Warranty and Return Policy

Please visit our website www.theSoundBay.com to review the warranty information and return policy.

Product Warranty Card

Product Model:	
Purchase date:	
Contact Phone #:	
Full name:	
Mailing Address:	

Note the content of this card shall not be altered without permission. Please keep this card to protect your lawful rights and interests.